




F9G, 3






Page 24 of 33





F9G. 6A


Plunger/ Support leg Settings	notch	notch	notch	notch	notch	notch	notch	notch	notch	notch
	loth	9th	8th	7th	6th	5th	4th	3th	2th	1st
	to 1	2	<u>۽</u>	<u>۽</u>	유	유	饣	ţ	to	\$
	Adjust to 10th notch	adjust to 9th notch	adjust to 8th notch	adjust to 7th	adjust to 6th	adjust to 5th notch	adjust to 4th notch	adjust to 3th notch	adjust to 2th notch	adjust to 1st notch
(cm)	0	05	.5–1	1-1.5	1.5–2	2-2.5	2.5–3	3-3.5	3.5-4.0	4.0-4.5




Page 26 of 33









Page 30 of 33

